

# SoundBoard - Fitting Instructions



**1** Sweep the area to make sure the floor is dust and dirt free.



**2** It's easy to cut the SoundBoards with a knife or saw. Cut the first board of every other row in half to allow the joints to be staggered.



**3** Apply Marmox Multibond to the black rubber side of the Sound Board.



**4** Alternatively you can comb on a full bed of cement based flexible tile adhesive.



**5** Leave a gap of 5mm around the edge of the room where the floor meets the walls. Lay the SoundBoard rubber side down onto the floor and press down firmly.



**6** It's important to squeeze some Marmox Multibond in the 5mm gap around the floor at the base of the walls.



**7** Then apply 'Marmox Reinforcing Tape' over all the joints. For wet areas use 'Marmox S/A Waterproof Tape'. Now the floor is ready to be tiled.



**8** If using undertile heating, apply the heat wire directly to the SoundBoard and then tile over the top.