

In-Charge™ Lockers - Installation

The locker must be within 1metre of a power socket.
 Care must be taken not to damage the cables during the movement of the locker.
 For additional security it is recommended the unit is fixed in place.
 When fixing care must be taken not to damage the cables.



STEP 1

Check delivery prior to unwrapping material. Unwrap the locker and remove power lead from the top compartment.



STEP 2

Lay locker on it's side in a clear area, prevent potential damage by resting the locker on a suitable surface if required.



STEP 3

Insert the cable through the hole in the back of the locker. Fit grommet and join the cables.



STEP 4

Lift locker taking care not to damage cable



STEP 5

Locate the locker and push any loose cable into the locker base.



STEP 6

CHECK RCD OPERATION

Insert the RCD adaptor into a 13 amp mains socket and Switch on. Press the RESET button. The ORANGE indicator should appear. Press the TEST button. The ORANGE indicator will disappear from the clear window.

DO NOT USE IF THE ORANGE INDICATOR REMAINS. STOP IMMEDIATELY.

Press the RESET button.

The RCD has now been set for safe use provided the ORANGE indicator shows in the clear window.



i Information
 If in doubt, contact the supplier.

🔨 Fixing the lockers is the responsibility of the installer. Check before drilling or fixing the suitability of the floor/wall.

🪜 Assemble and locate for use on a suitable level floor surface. Allow adequate working space.

📄 Read this Guide thoroughly before commencing assembly and retain for future reference.

⚠ Caution
 During assembly, ensure to:

♻ Dispose of packaging materials responsibly

👥 Assembly should be undertaken by two competent people, preferably suitably trained Locker installers.

🚧 Take care during assembly and in use, particularly when lifting or stretching and when using tools.